

Glove sizing guide

Industrial gloves fit differently than most gloves because of the materials used to provide protection. We recommend using our size charts and reviewing glove descriptions and materials.

Measure your hand (recommended)

Using a string or measuring tape, measure the circumference around the knuckles, excluding the thumb. Your hand should be open with the fingers together. Compare this measurement to the chart on the right to determine your glove size.

Or, print the chart below to help measure

Print the below glove chart at 100% size to assist with accurate measurement. Reducing or enlarging the printout will result in inaccurate measurements. Place your right hand on the glove chart so that the saddle of your thumb and index finger line up with the X. The measurement closest to the right edge of your hand will be the appropriate glove size.

Palm width x hand height	HexArmor® size
3.18 in. (8.1 cm) x 8.85 in. (22.5 cm)	5/XXS
3.3 in. (8.5 cm) x 9.25 in. (23.5 cm)	6/XS
3.4 in. (8.7 cm) x 9.6 in. (24.5 cm)	7/S
3.5 in. (9 cm) x 10 in. (25.5 cm)	8/M
3.8 in. (9.7 cm) x 10.2 in. (26 cm)	9/L
4 in. (10.2 cm) x 10.4 in. (26.5 cm)	10/XL
4.2 in. (10.7 cm) x 10.8 in. (27.5 cm)	11/XXL
4.4 in. (11.1 cm) x 11.2 in. (28.5 cm)	12/3XL

